

# FlangeBand® TileBud™

Install FlangeBand TileBud over a shower base or bathtub with an integral tiling flange

Installation Animations: [www.flangeband.com](http://www.flangeband.com)



## Sealing Components



Sealux-N Silicone  
(or equivalent)

4" (100mm)  
Sealux Strip

## Installation Accessories



Alcohol  
Wipes



Adhesive  
Spreading Spatula

# FlangeBand® TileBud™



If using a non-silicone sealant, thin set mortar or liquid waterproofing compound as the strip adhesive, do not mix that adhesive with the silicone applied over the tile flange. The process of bonding the strip to the wall and tile flange (10-13) should be done diligently before the sealant has skinned. In 3-wall enclosures, the process of bonding the strip to the wall can be done in stages.

**10-11.** (Bonding strip in stages) Onto the first side wall and a further 9" around the adjacent corner, apply and spread a zigzag line of silicone between the rim and wall line using the serrated edge of the spatula. Progressively align and touch-engage the upper strip portion with the wall adhesive and the lower fleece free strip portion with the unskinned silicone that extends over tile flange.

**12-13.** First, press the strip fully into the wall corner and then press strip firmly against remaining flat wall surfaces ensuring the lower fleece free portion of the strip bonds with the silicone applied over tile flange to form a waterproof seal. Continue this process for all subsequent walls. If using silicone as the strip adhesive, do not smear silicone over strip outer face or over wall above strip.